



















Feature operation

AutoDial		
Store	AutoDial 	AutoDial 
Use		AutoDial 
Display	Display 	AutoDial 






Call Forward		
Activate	Fwd 	Fwd 
Deactivate		
Reinstate	Fwd 	Fwd 
View number	Display 	Fwd 



Call Pickup		
		Pickup

Call Waiting		
Answer		Call Waiting
	(Hold)	
Return to first call		
	(Goodbye)	

Conference		
	Conf 	Conf 

Handsfree		
-----------	--	--

Activate		 (to end the call)
	(Handsfree)	(Goodbye)
Switch to handset		
Handset to handsfree		
	(Handsfree)	

Activate Headset		
		 (to end the call)
	(Headset)	(Goodbye)





Hold		
------	--	--



Place a call on hold		
	(Hold)	
Return to a held call		

Last Number Redial		
--------------------	--	--

Message		
		
		(Msg/Inbox)




Ring Again		
------------	--	--

Activate	RngAgn 	
When notified		RngAgn 
Deactivate		













Transfer		
	Trans 	Trans 

Adjust volume		
		or 
	(Volume +)	(Volume -)

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the Headset key.
	Replace the handset, or press  (Goodbye) to end the call.

Legend (continued)

Icon	Action
	Press a line/feature key.
	Dial a number.
	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
	Press the Services key once for Call Platform features, or press the Services key twice for local phone features.
	Press the Message/Inbox key.
	Press the Up/Down Navigation keys
	Press the Enter key
	Press the Headset key.
	Press the Handsfree key.
	Press the Mute (on/off) key.
	Press the Directory key.
	Press the Quit/Stop key.

Services and Telephone Options menus

Services menu		
---------------	--	--

		
(Services)		

Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1120E phones. Consult your system administrator.

The following are the most commonly used options:

Telephone Options menu		
------------------------	--	--

Volume adjustment

Pick one of:

Ringer				
Handset Listen				(Quit)
Handsfree Listen				
Headset Listen				
Buzzer				

Contrast adjustment

		
		(Quit)

Language		
----------	--	--

		
		(Quit)

Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.




Date/Time format		
------------------	--	--

		
		(Quit)

Local DialPad Tone		
--------------------	--	--

		
		(Quit)

Ring type		
-----------	--	--

	Play 	
		(Quit)

OnHook default path		
---------------------	--	--

		
		(Quit)

Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide* (NN43112-103).

Nortel IP Phone 1120E



*Note: If supported by your server, the data message waiting indicator provides a data alert. Contact your system administrator to find out if this feature is available for you.

To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.

LEGAL NOTICE

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Date: May 2009
Document Release: Standard 02.01
Document Number: NN43112-106
Copyright © 2006–2009 Nortel Networks
All Rights Reserved.

* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

NORTEL

www.nortel.com

IP Phone 1120E

For Nortel Communication Server 1000

Quick Reference Card

